
Codan 8350 to TS50 Kenwood

The following table shows the standard pin connections for the control cable:



ACC connector at rear of TS-50S

Codan Wiring Code
A = 13.8 V RED
B = EARTH BLACK
C = TUNE BLUE
D = SCAN GREEN
E = INDICATOR YELLOW
F = NOT USED

OPERATION PROCESS

- 1. Plug everything in incl small VSWR meter.
- 2. Put the radio to desired frequency
- 3. Put in CW mode @ 10 Watts
- 4. Press the momentary switch.
- 5. Press the PTT
- 6. Wait for the tune process to finish, aprox 5 secs from 10 mtrs to 80 mtrs.
- 7. Check VSWR on the inline meter.
- 8. Now increase power and change the emission mode from CW to preferred medium.
- 9. Should be between 1.1 and 1.6 across all bands, based on my testing.

Paul Ashby VK3MR 2.1.03 Kenwood TS-50s with Codan 9350 antenna.